

GCP-F3

Shown :

- GCP-F3 - Genus Cheeseplate for F3
- GARM - Genus Swing Arm by Noga
- SONY PMW-F3



Genus Top Cheeseplate for Sony PMW-F3L Camcorder

Specifically designed for the Sony F3 camera, the Genus GCP-F3 Cheese Plate attaches to the top of the camera housing and has bridge support to ensure there is no movement.

Series of 1/4" and 3/8" threaded sockets allow for attachment of the Genus Arm or Genus Spigots for pin-point positioning of you Monitor, Light or other accessories.



GENUSTECH